

LOCK & EXTENSION BAR LENGTHS

Count the number of direct or track mount fasteners spaced 12 inches Vertical or Horizontal mounts.

<u># OF FASTENERS</u>	<u>LOCK & EXTENSION BAR</u>	<u>CENTER BRACE</u>
2	19 In. mdl# LB019PKG	0
3	45 In. mdl# LB045PKG	0
4	57 In. mdl# LB057PKG	0
5	45 In. mdl# LB045PKG & (1) mdl# EB019	0
6	57 In. mdl# LB057PKG & (1) mdl# EB019	(1) mdl# RCB or CCB
7	45 In. mdl# LB045PKG & (1) mdl# EB045	(1) mdl# RCB or CCB
8	57 In. mdl# LB057PKG & (1) mdl# EB045	(1) mdl# RCB or CCB
9	71 In. mdl# LB071PKG & (1) mdl# EB045	(2) mdl# CCB
10	110 In. mdl# LB110PKG & (1) mdl# EB019	(2) mdl# CCB
11	84 In. mdl# LB084PKG & (1) mdl# EB057	(2) mdl# CCB
12	84 In. mdl# LB084PKG & (1) mdl# EB071	(2) mdl# CCB
13	84 In. mdl# LB084PKG & (1) mdl# EB084	(2) mdl# CCB
14	97 In. mdl# LB097PKG & (1) mdl# EB084	(2) mdl# CCB
15	110 In. mdl# LB110PKG & (1) mdl# EB084	(2) mdl# CCB
16	110 In. mdl# LB110PKG & (1) mdl# EB084	(2) mdl# CCB
17	110 In. mdl# LB110PKG & (1) mdl# EB097	(2) mdl# CCB

HALF PANEL EXTENSION BAR


Half Panel Extension Bar can be used in conjunction with Lock Bars and Extension Bars to add short configuration lengths. (Note Lock Bars and Extension Bars can be used in any combinations to achieve desired lengths.

12 In. mdl# HEB012

MOUNTING REFERENCE

Vertical and horizontal mount examples

Window and Door openings



● **Location of Fasteners for Vertical and Horizontal mount**